

STANDARD OPERATING INSTRUCTIONS FOR USING BLAZE DEG LIQUID WICK FUELS

NEVER

NEVER PLACE LIT FUEL CANS DIRECTLY ON TABLE OR TABLECLOTH.
NEVER USE A LIT CAN TO LIGHT ANOTHER CAN.
NEVER LIGHT THE FUEL WHILE HOLDING THE CAN.
NEVER CARRY CHAFING DISHES OR BEVERAGE URNS WITH LIT CANS.
NEVER TOUCH CANS WHILE STILL HOT.
NEVER LEAVE LIT BLAZE UNATTENDED.
NEVER ALLOW TABLECLOTH & TABLE DECORATIONS TO COME IN CLOSE PROXIMITY OF THE FLAME.
NEVER ALLOW HAIR TO FALL NEAR FLAME.
NEVER USE HANDS TO EXTINGUISH FLAME.
NEVER BLOW OUT FLAME.

ALWAYS

ALWAYS KEEP AWAY FROM CHILDREN.
ALWAYS USE CAUTION WHEN HANDLING OPEN FLAME PRODUCTS.
ALWAYS READ THE CAN LABEL PRIOR TO LIGHTING.
ALWAYS WASH FUEL RESIDUE FROM HANDS.
ALWAYS PLACE THE CAN UNDERNEATH THE CHAFING DISH OR BEVERAGE URN BEFORE LIGHTING.
ALWAYS MAKE SURE CANS ARE PLACED SECURELY IN EQUIPMENT.
ALWAYS USE A LONG STEMMED MATCH OR LONG HANDLED LIGHTER TO LIGHT THE FUEL CUPS.
ALWAYS BURN ON HEAT RESISTANT SURFACE.
ALWAYS USE FLAME RETARDANT MATERIALS AROUND FUEL AREA, i.e. TABLECLOTH, NAPKINS & SKIRTING.
ALWAYS USE METAL SNUFFING DEVICE TO EXTINGUISH.
ALWAYS WAIT UNTIL CAN IS COOL BEFORE TOUCHING.

DIRECTIONS FOR USE:

Place the chafing dish on a level, heat resistant surface, away from napkins and table decorations. Twist the top to open. Remove the water pan and food pan. Place one or two cans of fuel under the chafing dish in the designated holder or tray. NEVER use more than two cans of fuel at a time under a chafing dish. Always begin with HOT water. Fill chafing dish water pan with hot water to the indicated level marked on water pan. Check water pan periodically to ensure a sufficient water level is maintained. **NEVER USE WITHOUT WATER!** Light fuel with a long stemmed match or long handled lighter and adjust the heat cup to the desired opening. The wick is pre-set; do not remove wick or fuel from can. Always allow the can to cool before handling.

TIP: If you have trouble lighting the wick, simply invert the can to allow wicking action to begin. Then light as usual. Do not throw away the can until all the fuel has been used. Recycle container.